

Notes:



Notes:

1. Use Simple Green to wipe down surface of china cabinet to clear any dust, dirt, etc.
2. Once clean, wipe off with water and lint free t-shirt rag.
3. Thoroughly shake the One Step Paint™ can for 1-2 minutes.
4. Use an opener to open One Step Paint™. Stir thoroughly with stir stick. Depending how well the chalk has settled, you may need to shake, stir/shake, stir until the paint is mixed well.
5. Tape off cabinet exterior to avoid any overspray, as well as removing any shelves (if possible) to paint separately.
6. Using the Graco® Airless Sprayer, coat your object with a nice, even coat of *Rugol* One Step Paint™. (You can also brush on the One Step Paint™ with a synthetic brush). Do not apply the paint too thick, as it may crack when drying. **When using the Graco® Airless Sprayer you may need to dilute paint so that it can flow easily through sprayer. This is particularly the case when using light & medium bases and pre-mixed colors. However, dark bases usually do not have to be diluted).*
7. Once the first coat has been applied, allow to dry 30 - 45 minutes.
8. Apply second coat of One Step Paint™. Allow to dry 30 - 45 minutes.
9. Tape off edges *inside* of the cabinet.
10. Using a synthetic brush, paint the outside of the cabinet (we used *Nottoway* One Step Paint™). Allow to dry 30 - 45 minutes
11. Apply second coat of *Nottoway* One Step Paint™.. Allow to dry 30 - 45 minutes.
12. Use One Step Paint™ (we used *Nottoway*) to paint the hardware. You may need 2 coats. Allow to dry 30 - 45 minutes.
13. Install any/all drawers, doors, and hardware on china cabinet. (We left the doors off of our china cabinet and added baskets).
14. Using a round hog's hair brush and Light Antique Wax™, get just enough wax to cover the tips of the bristles.
15. Use the cardboard palette to offload some wax from the brush. **Always off-load wax - never go directly from the wax to your piece, as this creates an undesirable wax build-up.*
16. Apply the Light Antique Wax™ over the entire piece. Do not use not long, symmetri-cal strokes, but move brush in a “cross-hatch” pattern.
17. Allow Light Antique Wax™ to dry
18. Buff your piece using a lint-free t-shirt rag as you would buff a shoe (hit-drag mo-tion). This achieves that beautiful patina shine.
19. Now you get to “Enjoy the Bragging Rights™!”

Notes:



Step by Step





One Step Paint Color Combinations



Brooks Grey & Vintage Affliction



Get in Gear & Tick Tock



Selznick Grey & Spa White



Graphite & Selznick Grey



Cartouche Green & Robin's Egg Blue



Charm School & Palmer Pink



Massey Hill & Palm Beach



Rugo & Paige Blue



Good Man is Hard to Find & Luxe Grey



Good Man is Hard to Find & Linen



Tick Tock & Indian Summer



Cherbourg & Dunavant Green



Massey Hill & Drama Queen



Black & Charm School



Tick Tock & Cartouche Green



Cartouche Green & Ballet White



Nottaway & Atelier



Brooks Grey & American Dream